


# Quick Reference Guide



## Teufel Streamer

POWERED BY  RAUMFELD



For detailed online documentation,  
please visit

<http://manual.teufelaudio.com>

# Teufel

# Contents

---

|  |   |                                |    |
|--|---|--------------------------------|----|
| General Notes And Information .....          | 2 | Setup.....                     | 6  |
| Unpacking.....                               | 3 | Configuration .....            | 7  |
| Operational Controls and<br>Connections..... | 4 | Operation .....                | 8  |
| Preparations .....                           | 6 | Troubleshooting.....           | 10 |
|  |   | Declaration Of Conformity..... | 11 |

## General Notes and Information

---

### Proper use

The Teufel Streamer serves to play back audio data from a network or from an external player directly via a HiFi system, soundbar or similar.

Only use the Teufel Streamer as described in this quick reference guide and the online documentation. Any other use will be deemed as not in accordance with the instructions and may lead to damage of property or even persons.

The manufacturer accepts no liability for damage caused by improper use.

The device is intended for private use only.

### Safety notes

The enclosed brochure “Important product information” contains general safety notes which you should always observe to protect yourself and third parties. Also be sure to observe any warning notes contained in this quick reference guide.






Before operating the device, please first read the safety notes, this quick reference guide and the online documentation carefully. This is the only way to use all functions safely and reliably. Keep the enclosed documents in a safe place and also be sure to pass it on to any subsequent owner.

# Unpacking


## Package contents

- (1) Teufel Streamer
  - (2) Mains adapter
  - (3) RCA audio cable
  - (4) Brochure “Important product information”
- Check that all items have been delivered and that nothing is damaged. Do not use the device if it is damaged, instead, contact our customer service department (see back page).
  - Please keep the packaging for the duration of the warranty period.



# Operational Controls and Connections


## Top side



- (5) Preset buttons  
Push and hold: save current playback.  
Tap: play saved music.
- (6) Pause/play  
Tap: Pause/play.  
Push and hold: Standby
- (7) Skip track back/forward

- (8) Control button  
Tap to select LINE IN input.  
Further possibilities to assign the control button using the app will be available in future updates. More information can be found at:  
<http://manual.teufelaudio.com/controlbutton>.
- (9) Increase/decrease the volume

## Back side



(10) Connector jack for mains adapter

(11) USB 2.0 jack  
For restoring the firmware and for sharing music.  
Music saved on a USB stick will be made available under “My music” if the stick is connected to the USB port of the host device. In the network settings, you can see which device acts as a host in your system.

(12) Network connection (LAN)

(13) Optical output (digital) e.g. to the amplifier via TOSLINK cable

(14) (Analogue) audio input for external players via RCA cable.

(15) (Analogue) audio output e.g. to the amplifier via RCA cable.

(16) Bluetooth pairing button  
Tap to set the Teufel Streamer to pairing mode.

(17) Setup button  
Push during the setup process once asked to do so.

(18) Reset button  
Hold for 8 seconds while the device is on to reset the Teufel Streamer to the factory default settings.

# Preparations

---

To be able to integrate Teufel Streaming products with Raumfeld technology in your network and to ensure smooth operation, we recommend an up-to-date, high performance router with a broadband Internet connection.

Make sure that the Wi-Fi router is active, has the latest firmware and is able to access the Internet.

To the extent possible, the router should be positioned in the middle of your home in order to ensure an adequate Wi-Fi signal throughout your home.

# Setup

---

- Set up the Teufel Streamer in the desired location and connect it to the mains supply with the mains adapter.
- If desired, connect your peripheral devices.
  - Analogue external player: Via RCA cable to LINE IN (14).
  - Digital amplifier: Via TOSLINK cable to OPT OUT (13).
  - Analogue amplifier: Via RCA cable to LINE OUT (15).



*The device must be switched on (LEDs light up) so that the signal is played back.*

# Configuration

- Make sure that your smartphone or tablet is registered in your home Wi-Fi.
- Have the Wi-Fi password for your router ready.
- Load the TEUFEL RAUMFELD APP from the Play Store/App Store.
- Once you have started the app, the setup wizard will guide you through the setup process.
- You can find more information about setting up your Teufel streaming system at [http://  
manual.teufelaudio.com/setup](http://manual.teufelaudio.com/setup). The tips in chapter „Trouble-shooting“ on page 10 should also be helpful.



*Integration of other devices  
in an existing Teufel  
streaming system:*

- *You do not have to set up the entire system again. You can use the app to add new devices (under “Settings”).*

# Operation

---

## Standby

The Teufel Streamer switches to standby mode after a few minutes of inactivity have elapsed. The timespan leading up to the beginning of the standby mode can be configured in the settings menu within the app. To manually send the device into standby mode, simply hold down the play/pause button (6) for about 2 seconds.

## Preset buttons

Your Teufel Streamer has 3 programmable preset buttons (5). They allow you to access your favourite radio station, a playlist or any other music with just the push of a button.

### Programming preset buttons

1. Make sure that the Teufel Streamer is operational.
2. Use the Teufel Raumfeld app to play any music on your Teufel Streamer (e.g. a radio station, an album, a playlist or all tracks of an artist).
3. As soon as the music is played back, push a preset button and hold it until you hear a signal tone. The played back music will be saved for this preset button.

## Accessing saved content

- Tap the preset button to access saved music with just the push of a button and to play it back on the Teufel Streamer.

## Control button

The control button (8) is configured by factory default so that by pressing it the LINE IN is selected.

With the Teufel Raumfeld app, you can also assign other functions to the control button. For a detailed description of the available functions as well as instructions on how to assign functions to buttons visit:

<http://manual.teufelaudio.com/controlbutton>.

## Spotify Connect

With Spotify Connect, you can play music on your mobile, tablet or PC on your Teufel Streamer via the Spotify app. Please note that you will require Spotify Premium to use Connect.

1. Connect your Teufel Streamer to your wifi network.
2. Open up the Spotify app on your phone, tablet or laptop using the same wifi network.
3. Play a song and select “Devices Available”.
4. Select your Teufel Streamer and



start listening.

## **Connecting via Bluetooth®**

You can connect compatible devices such as most smartphones and tablets to your Teufel Streamer via Bluetooth® (pairing). The sound of the smart device is then played by the Teufel Streamer.

1. Turn on the Bluetooth® function on your smart device.
2. Tap the Bluetooth pairing button (16) on the back side of the device. The Bluetooth LED in the button will now blink until pairing is complete (no more than 60 seconds).
3. Let your smartphone search for Bluetooth® devices (you can find more information in the user manual of your smart device). After the search run, the “Teufel Streamer” should also be present in the list of detected devices.
4. Select “Teufel Streamer” from the list of detected devices. If your smart device requires the entry of a PIN code, enter the PIN code “0000” set by factory default.
5. Pairing is now complete and the smart device is linked to the Teufel Streamer. The

Teufel Streamer will now play back all sounds that would otherwise be played by your smart device.

- To terminate the Bluetooth® connection, switch the Bluetooth® function on your smart device off.

# Troubleshooting


The following advice should help you to solve problems. If this does not work, our online documentation will provide help:

<http://manual.teufelaudio.com>

| Problem                                 | Possible cause/solution  |
|---|--|
| The LEDs do not illuminate.             | Make sure that power is supplied. Check to make sure that the mains adapter is securely seated.  |
| Setup fails.                            | <p>Restart your router and your smartphone or tablet.</p> <p>Set up the device near your router and switch any repeaters off for the duration of the setup process. If your router provides guest access, do not use it to connect your Teufel streaming devices.</p> <p>Read the notes in our online documentation at: <a href="http://manual.teufelaudio.com/setup">http://manual.teufelaudio.com/setup</a>.</p>   |
| Music playback skips or is interrupted. | <p>It is possible that one or more Teufel device(s) do not have a Wi-Fi signal or it is too weak.</p> <p>Place the devices closer to the router, try alternative setup locations or connect devices, which are set up far away, with an Ethernet cable. In the event of problems with multi-room systems with three or more devices, we recommend connecting at least one of the devices with an Ethernet cable and setting it as the host.</p> <p>As a test, refrain from using repeaters. If applicable, use an audio stream with low resolution.</p> <p>Also visit the website of the router manufacturer for tips on how to improve your Wi-Fi.</p> <p>You can find more information in our online documentation: <a href="http://manual.teufelaudio.com">http://manual.teufelaudio.com</a>.</p> |

|  |  |
|--|--|
| <p>The app is not connected or fails to locate the configured streaming devices.</p> | <p>Make sure that the Teufel streaming devices and the smart device are operated with the Teufel Raumfeld App on the same Wi-Fi. Restart your router. Briefly disconnect your Teufel streaming devices from the power supply and then start them again.</p> <p>You can find more information in our online documentation: <a href="http://manual.teufelaudio.com">http://manual.teufelaudio.com</a>.</p> |
| <p>I would like to reset the device.</p>   | <p>Notice: By resetting the device, all system configuration settings will also be reset.</p> <p>Resetting the device: When the device is switched on, use a paper clip that has been bent straight to push the reset button (18) and hold it down until the device restarts (for at least 8 seconds).</p>   |

## Declaration Of Conformity

 Lautsprecher Teufel GmbH hereby declares that this product complies with the requirements of the directives 2014/30/EU, 2014/35/EU and 2014/53/EU to the extent they are installed and used in accordance with the instructions of the manufacturer. The full text of the EU declaration of conformity is available at the following Internet address:

[www.teufelaudio.com/declaration-of-conformity.html](http://www.teufelaudio.com/declaration-of-conformity.html)

The following radio frequency bands and radio transmitting powers are used in this product:

| Radio network | Frequency bands in MHz          | Max. transmission power in mW/dBm |
|---------------|---------------------------------|-----------------------------------|
| Bluetooth     | 2400–2483.5                     | 2.5/4                             |
| Wi-Fi 2.4 GHz | 2412–2472                       | 40/16                             |
| Wi-Fi 5 GHz   | 5180–5320; 5500–5700; 5745–5825 | 25/14                             |

You can find further technical data about the product on our website.

# Teufel

Please contact our customer service department with any questions, suggestions, or complaints:

**Lautsprecher Teufel GmbH**  
**BIKINI Berlin**  
**Budapester Str. 44**  
**10787 Berlin (Germany)**

Great Britain: +44 33 08 08 04 89

Other countries: 00800 200 300 40

Online support: <http://manual.teufelaudio.com>

Contact form: [www.teufelaudio.com/contact](http://www.teufelaudio.com/contact)

No responsibility is assumed for the correctness of this information.  
Technical changes, typographical errors and other errors reserved.